

2004 Acura TL – Radio ■ Factory Amp Wiring Map

Scope: Radio to factory amplifier signal path only. Speaker destinations not mapped.

Radio Connector C (26-pin)

C Pin	Wire Color	Connects To
1	Brown	Amp D6
2	Red / Blue	Amp D5
3	Blue	UNCONFIRMED
4	Orange / Pink	UNCONFIRMED
5	Green / Orange	UNCONFIRMED
6	Blue / White	UNCONFIRMED
7	Yellow / Green	Amp D14
8	Red / Yellow	Amp D7
9	White	UNCONFIRMED
10	Blue	UNCONFIRMED
11	Green / White	Amp D13
12	White / Green	Amp D12
13	Blue / Red	UNCONFIRMED
14	Turquoise / Black	UNCONFIRMED
15	Red	UNCONFIRMED

Radio Connector B (20-pin)

B Pin	Wire Color	Connects To
1	Green / Yellow	UNCONFIRMED
2	Yellow / Red	UNCONFIRMED
3	Green / Red	UNCONFIRMED
4	White / Red	UNCONFIRMED
5	Orange	Amp D3
6	White	Amp D4
7	Black	Amp D1
8	Green	Amp D2

B Pin	Wire Color	Connects To
9	Red / Black	UNCONFIRMED
10	Yellow	Amp E8
11	Brown	UNCONFIRMED
12	Red	Amp D10
13	Yellow	Amp D11
14	Gray	Amp D8
15	Blue	Amp D9
16	Red	UNCONFIRMED
17	Black	Amp E7
18	Empty	—
19	Empty	—
20	Empty	—

Amp Connector D – Inputs from Radio

D Pin	Wire Color	From
1	Black	Radio B7
2	Green	Radio B8
3	Orange	Radio B5
4	White	Radio B6
5	Red / Blue	Radio C2
6	Brown	Radio C1
7	Red / Yellow	Radio C8
8	Gray	Radio B14
9	Blue	Radio B15
10	Red	Radio B12
11	Yellow	Radio B13
12	White / Green	Radio C12
13	Green / White	Radio C11
14	Yellow / Green	Radio C7

Amp Connector E – Outputs to Speakers

E Pin	Wire Color	From
1	Green / Red	—
2	Yellow / Black	—
3	Blue / Yellow	—
4	Green / White	—
5	Red / Yellow	—
6	Brown / White	—
7	Black	Radio B17
8	Yellow / White	Radio B10
9	Red / Blue	—
10	Green	—
11	Blue	—
12	Yellow	—
13	Purple	—
14	Red	—

Aftermarket Radio Color Legend

Power / Control:

- Yellow: Constant 12 V
- Red: ACC / Ignition
- Black: Ground
- Blue / Blue-White: Amp remote / antenna

Speaker Outputs:

- Front Right: Gray (+) / Gray-Black (-)
- Front Left: White (+) / White-Black (-)
- Rear Right: Violet (+) / Violet-Black (-)
- Rear Left: Green (+) / Green-Black (-)